

		Junction Box				Wall Mount			Ceiling Mount		Flush Mount		Pole Mount Bracket	Corner Mount Bracket	Gang Plate
		LUM-A20-JB-FX-BT(W)(B)	LUM-A20-JB-VF-BT(W)(B)	LUM-A20-JB-FX-DOM(W)(B)	LUM-A20-JB-VF-DOM(W)(B)	LUM-A20-WMB-TD(W)(B)	LUM-A20-WMB-FX-TD(W)(B) ¹	LUM-A20-WMB-VF-TD(W)(B) ²	LUM-A20-CM-FX-TD(W)(B) ³	LUM-A20-CM-VF-TD(W)(B) ⁴	LUM-A20-FM-FX-DOMW	LUM-A20-FM-VF-DOMW	LUM-A20-PMB-W	LUM-A20-CMB-W	LUM-A20-GANG-PLATE(W)(B)
		Housing		Accessory											
Turret	LUM-220-IP-TF LUM-520-IP-TF LUM-520-IP-TFC LUM-820-IP-TF	•				•	•		•				•	•	•
	LUM-420-IP-TM LUM-820-IP-TM		•			•		•		•			•	•	•
Dome	LUM-220-IP-DF LUM-520-IP-DF LUM-820-IP-DF			•		•	•		•		•		•	•	•
	LUM-420-IP-DM LUM-820-IP-DM				•				•		•		•	•	•
	LUM-520-IP-DFT					•									•
Bullet	LUM-220-IP-BF LUM-520-IP-BF	•					•		•				•	•	•
	LUM-520-IP-BFC LUM-820-IP-BF	•					•		•				•	•	•
	LUM-420-IP-BM LUM-820-IP-BM		•					•		•			•	•	•

¹ Requires junction box: LUM-A20-JB-FX-BT, LUM-A20-JB-FX-DOM
² Requires junction box: LUM-A20-JB-VF-BT, LUM-A20-JB-VF-DOM
³ Requires junction box: LUM-A20-JB-FX-BT, LUM-A20-JB-FX-DOM
⁴ Requires junction box: LUM-A20-JB-VF-BT, LUM-A20-JB-VF-DOM